

crossXIO



User Manual SCT-IPE5100

HDMI 2.0/USB AV over IP Encoder

All Rights Reserved

Version: SCT-IPE5100_2026 V1.0.1

HDMI 2.0/USB AV over IP Encoder

Preface

Read this user manual carefully before using the product. Pictures shown in this manual are for reference only. Different models and specifications are subject to real product.

This manual is only for operation instruction, please contact the local distributor for maintenance assistance. The functions described in this version were updated till June, 2021. In the constant effort to improve the product, we reserve the right to make functions or parameters changes without notice or obligation. Please refer to the dealers for the latest details.



SAFETY PRECAUTIONS

To ensure the best from the product, please read all instructions carefully before using the device. Save this manual for further reference.

- Unpack the equipment carefully and save the original box and packing material for possible future shipment.
- Follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- Do not dismantle the housing or modify the module. It may result in electrical shock or burn.
- Using supplies or parts not meeting the products' specifications may cause damage, deterioration or malfunction.
- Refer all servicing to qualified service personnel.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Do not put any heavy items on the extension cable in case of extrusion.
- Do not remove the housing of the device as opening or removing housing may expose you to dangerous voltage or other hazards.
- Install the device in a place with fine ventilation to avoid damage caused by overheat.
- Keep the module away from liquids.
- Spillage into the housing may result in fire, electrical shock, or equipment damage. If an object or liquid falls or spills on to the housing, unplug the module immediately.
- Do not twist or pull by force ends of the cable. It can cause malfunction.
- Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power to the device before cleaning.
- Unplug the power cord when left unused for a long period of time.
- Information on disposal for scrapped devices: do not burn or mix with general household waste, please treat them as normal electrical wastes.

HDMI 2.0/USB AV over IP Encoder

Table of Contents

1. Introduction 2

 1.1. Overview 2

 1.2. Features 2

 1.3. Package Contents 4

 1.4. Specifications 5

 1.5. Panel Description 7

2. Installation 9

3. Typical Applications 10

 3.1. Application Example 1 10

 3.2. Application Example 2 11

 3.3. Application Example 3 12

4. Hardware Installation 13

5. IP Address Identification 13

6. Signal Switching Behavior 14

7. Device Control Overview 15

8. Customer Service 16

 8.1. Warranty 16

 8.2. Scope 16

 8.3. Warranty Exclusion: 16

 8.4. Documentation: 16

HDMI 2.0/USB AV over IP Encoder

1. Introduction

1.1. Overview

The SCT-IPE5100 series encoders are designed to work with SCT-IPD5100 series decoders for UHD media up to 3840 x 2160@60Hz 4:4:4 to be switched and distributed over standard Gigabit Ethernet networks, providing complete end-to-end streaming systems, where audio, video together with USB signals can be routed separately or as a whole. Equipped with Dante technology, they realize perfect interconnectivity and interoperability with Dante audio systems.

Dual Ethernet ports are equipped. HDCP 2.2/2.3 specifications are employed. A local area network is covered with a range up to 330ft (100m) over a single Cat 5e cable or above. Independent analog audio input/output is included. Control methods of Telnet/SSH/REST API and SCT-IPCX controller are provided. The encoders are ideal for any low latency and signal routing applications, such as homes, classrooms, conference rooms, sport bars, auditoriums, etc.

1.2. Features

- Includes one HDMI and one USB-C inputs with support of flexible input switching modes: Auto, Manual and Priority.
- The USB-C input supports DP 1.3 to HDMI 2.0, local USB 3.0 & remote USB 2.0 transmission, Ethernet passthrough and up to 100W charging.
- Built-in dual Ethernet ports, any one of which can be used for transmission of A/V streams, control data and Dante audio streams.
- The USB-B host port supports local USB 3.0 & remote USB 2.0 transmission, and Ethernet passthrough.

HDMI 2.0/USB AV over IP Encoder

- Two USB type-A ports support USB 3.0 transmission with data rate up to 5Gbps.
- Supports input and output resolutions up to 3840 x 2160@60Hz 4:4:4.
- Supports HDR10 and Dolby Vision.
- Supports CEC.
- Supports multi-channel audio up to PCM 7.1, Dolby Atmos, DTS HD Master and DTS:X.
- Configurable audio input/output direction.
- HDMI ARC audio return.
- HDCP 2.2/2.3 compliant.
- Flexible routing policies, allowing audio, video and USB signals to be routed separately or as a whole throughout the matrix system.
- Delivers audio, video, USB and power signals up to 328ft/100m over a single Cat 5e cable or above.
- Supports point-to-point, point-to-multipoint, multipoint-to-point, multipoint-to-multipoint applications.
- Supports PoE to be remotely powered by compatible power source equipment such as a PoE-enabled Ethernet switch, eliminating the need for a nearby power outlet.
- Supports DHCP by default, and will fall back to Auto-IP if there's no DHCP server in the system.
- Controlled by Telnet/SSH/REST API and IP controller.
- Supports communications protocols of Telnet, SSH, HTTP, and HTTPS.
- Supports 2 x 2 Dante audio transmission.

HDMI 2.0/USB AV over IP Encoder

1.3. Package Contents

- 1 × Encoder
- 1 × 3.5mm 5-pin Phoenix Male Connector
- 4 × Mounting Brackets
- 4 × Mounting Screws
- 1 × User Manual

HDMI 2.0/USB AV over IP Encoder

1.4. Specifications

Video	
Input Video Port	1 × USB-C; 1 × HDMI Type A (19 pins)
Input Video Type	HDMI 2.0, HDCP 2.2/2.3
Input Resolutions	3840 × 2160p@24/25/30/50/60Hz 4:4:4, 1920 × 1200@50/60Hz, 2400 × 1350p@60Hz, 1920 × 1080p@24/25/30/50/60/100/120Hz, 1920 × 1080i@50/60Hz, 1680 × 1050@60Hz, 1600 × 1200@60Hz, 1600 × 900@60Hz, 1400 × 1050@60Hz, 1440 × 900@60Hz, 1366 × 768@60Hz, 1360 × 768@60Hz, 1280 × 1024@60Hz, 1280 × 960@60Hz, 1280 × 800@60Hz, 1280 × 768@60Hz, 1280 × 720p@60/100/120Hz, 1024 × 768@60Hz, 800 × 600@60Hz, 720 × 576p@50Hz, 720 × 480p@60Hz, 640 × 480p@60Hz
Output Video Port	2 × RJ-45; 1 × HDMI Type A (19 pins)
Output Video Type	IP Stream; HDMI 2.0, HDCP 2.2/2.3
Output Resolutions	Up to 3840 × 2160p@60Hz 4:4:4
Average Encoding Data Rate	3840 × 2160@60Hz: 650Mbps (avg) / 900Mbps (max)
Input/Output Video Signal	0.5–1.2 V p-p
Input/Output DDC Signal	5 V p-p (TTL)
Video Impedence	100Ω
Maximum Data Rate	18Gbps (6 Gbps per color)
Maximum Pixel Clock	600MHz

Audio	
Input Audio Port	1 × USB-C; 1 × HDMI Type-A; 1 × 3.5mm 5-pin phoenix connector (configurable)
Input Audio Type	<ul style="list-style-type: none"> HDMI/USB-C IN: Fully supports audio formats in HDMI 2.0 specification, including PCM 2.0/5.1/7.1, Dolby TrueHD, Dolby Atmos, DTS-HD Master Audio and DTS:X AUDIO IN: Analog
Output Audio Port	2 × RJ-45; 1 × HDMI; 1 × 3.5mm 5-pin phoenix connector (configurable)
Output Audio Type	<ul style="list-style-type: none"> LAN/HDMI: Fully supports audio formats in HDMI 2.0 specification, including PCM 2.0/5.1/7.1, Dolby TrueHD, Dolby Atmos, DTS-HD Master Audio and DTS:X AUDIO OUT: Analog

HDMI 2.0/USB AV over IP Encoder

Audio	
Dante Audio Type	LPCM 2.0, 44.1/48/88.2/96 KHz

USB	
USB-C	<ul style="list-style-type: none"> • USB Compliance: USB 3.0 (Local: USB 3.0, Remote: USB 2.0) • Max USB Data Rate: 5Gbps • Charging Compliance: PD 3.0 • Max Charging Power: 100W • Max Ethernet Data Rate: 1Gbps
USB-B	<ul style="list-style-type: none"> • USB Compliance: USB 3.0 (Local: USB 3.0, Remote: USB 2.0) • Max USB Data Rate: 5Gbps • Max Ethernet Data Rate: 1Gbps
USB-A	<ul style="list-style-type: none"> • USB Compliance: USB 3.0 • Max USB Data Rate: 5Gbps • Max Charging Power: 5V@3.0A (Two USB-A ports share a total 3.0A output)


Control	
Control Method	Telnet/SSH/REST API, IP Controller

General	
Operating Temperature/ RH	32–113°F (0– 45°C), 10%–90% RH, non-condensing
Storage Temperature/ RH	-4–158°F (-20–70°C), 10%–90% RH, non-condensing
ESD Protection	Human body model: ±8kV (air-gap discharge) / ±4kV (contact discharge)
Power Supply	20V DC 10A; PoE+
Power Consumption (Max)	<ul style="list-style-type: none"> • Typical 12W (device only) • 135W (with 100W USB-C charging output)
Dimensions (W × H × D)	8.46" × 0.98" × 6.30" (215 mm × 25 mm × 160 mm)
Net Weight	2.22lbs (1.01kg)

HDMI 2.0/USB AV over IP Encoder

1.5. Panel Description


Front Panel



#	Name	Description
1	POWER LED	<ul style="list-style-type: none"> On: The device is powered on. Blinking: The device is booting. Off: The device is powered off.
2	STATUS LED	<ul style="list-style-type: none"> On: The device is working properly. Blinking: The device is connected to the network but doesn't detect valid signal input. Blinking slowly: The device is being upgraded. Blinking quickly: Find me function is activated through Telnet/SSH/REST API for positioning a certain device. For more information refer to the separate API document. Off: The device is not connected to the network.
3	USB-C ⚡ LED	<ul style="list-style-type: none"> On: The USC-C charging function is available. Off: The USB-C charging function is not available.
4	USB-C IN LED	<ul style="list-style-type: none"> On: The corresponding input channel is selected, and a valid A/V signal is detected.
5	HDMI LED	<ul style="list-style-type: none"> Blinking: The corresponding input channel is selected, and there is a 5V signal input, but no valid A/V signal is detected. Off: The corresponding input channel is not selected. / The corresponding input channel is selected but no 5V signal is detected.
6	USB 3.0	2 × USB 3.0 (5Gbps) Type-A ports. Connect to USB peripherals for USB extension or roaming. Note: Two USB-A ports share a total current output of 3.0A.

HDMI 2.0/USB AV over IP Encoder

Rear Panel



#	Name	Description
1	20V	DC 20V power connector. Connect to a DC 20V 10A power adapter for power input.
2	RESET Recessed Button	<ul style="list-style-type: none"> Short press (for not more than 1 second) then release to reboot the device. Press and hold for at least five seconds then release to reset the device to its factory default values. <p>Note: When the settings are restored, your custom data is lost. Therefore, exercise caution when using the RESET button.</p>
3	LAN1 (POE+)	By default, each of the LAN1 (POE+) and LAN 2 ports can be connected to an Ethernet switch for transmission of A/V streams, Dante audio streams and control data.
4	LAN2	<p>For LAN1 (POE+):</p> <ul style="list-style-type: none"> Supports PoE+. <p>For LAN2:</p> <ul style="list-style-type: none"> When LAN2 is configured as an <i>independent Dante port**</i>, it is for transmission of Dante audio streams, and LAN1 (POE) is for transmission of A/V streams and control data. Note: **This configuration can be implemented through the IP controller (SCT-IPCX). For more information, refer to the controller's Web UI configuration guide. <p>IMPORTANT: To prevent network loop, do not connect both ports to the same network. Ensure that each port is connected to a separate and distinct network.</p>
5	USB HOST	Connect the USB-B port to a computer for remote USB 2.0 and/or local USB 3.0 transmission, as well as for Ethernet pass-through.
6	USB-C IN	Connect the USB-C port to a USB-C source. This port supports transmission of DP 1.3, HDMI 2.0, remote USB 2.0 and/or local USB 3.0, Ethernet pass-through, as well as up to 100W charging. Tip: Charging of the attached peripheral is available only

HDMI 2.0/USB AV over IP Encoder


#	Name	Description
		when the device is powered by the DC power instead of by PoE+.
7	HDMI IN	19-Pin HDMI Type-A port. Connect to an HDMI source. This port supports HDMI 2.0b, HDCP 2.3 and bandwidth to the maximum of 18G.
8	HDMI OUT	19-Pin HDMI Type-A connector. Connect to an HDMI display.
9	AUDIO IN/OUT	5-Pin 3.5mm phoenix connector for balanced analog audio input or output. This port can be configured as AUDIO IN or AUDIO OUT through API commands. <ul style="list-style-type: none"> AUDIO IN: Connect to an audio source for audio input. AUDIO OUT: Connect to an audio receiver for audio output. Default setting: AUDIO OUT

2. Installation

Note: Before installation, ensure the device is disconnected from the power source.

To install the device on a suitable location, follow the steps below:

1. Attach the mounting brackets to both side panels of the device using the included screws (two screws per side).




2. Mount the device with the attached brackets to the desired location using user-supplied screws (not included).

HDMI 2.0/USB AV over IP Encoder


3. Typical Applications

3.1. Application Example 1




HDMI 2.0/USB AV over IP Encoder

3.2. Application Example 2



HDMI 2.0/USB AV over IP Encoder


3.3. Application Example 3



In this application, LAN1 (PoE+) transmits A/V streams and control data, while LAN2 transmits Dante audio streams to a standalone network. The two Ethernet ports connect to separate networks.

HDMI 2.0/USB AV over IP Encoder

4. Hardware Installation



Note: Connect encoders and decoders to power adapters if the Ethernet switch doesn't support PoE.

5. IP Address Identification

The device's default IP setting is DHCP. Ensure that a DHCP server is available in the network so that the device can obtain a valid IP address during deployment. If no DHCP server is available—for example, when the device is connected directly to a computer—the device is assigned a default IP address in the range of 169.254.X.Y. The assigned IP address can be identified via the OSD or API Commands.

HDMI 2.0/USB AV over IP Encoder

6. Signal Switching Behavior

The device provides three input switching modes between USB-C IN and HDMI IN: Auto, Manual, and Priority.

Auto

- In Auto mode, input switching follows “Last In, First Out” rule. The device automatically switches to the most recently connected input source and outputs it. If the currently selected video source is disconnected, the device automatically switches to the other available source.
- If both input ports are connected to video sources when the device powers on, the device selects the input according to the default priority order (USB-C IN > HDMI IN).

For example:

- If a USB-C source is connected, it will be selected.
- If not, the device switches to the HDMI source.

Manual

- In Manual mode, the device switches directly to the specified video source.
- If the specified source is invalid (e.g., in standby mode or not connected), no video signal will be output.

Priority

- In Priority mode, when both input ports are connected at power-on, the device selects the source with the higher priority.
- If the selected source is disconnected, the device automatically switches to the other available source.
- The priority order for the two input ports can be defined through API commands.

HDMI 2.0/USB AV over IP Encoder

Note:

- The default input switching mode is Auto.
- The switching mode can be configured via API commands. For details, refer to the separate API document.

7. Device Control Overview

The device can be controlled and configured through the SCT-IPCX controller, including routing of audio, video and USB signals, configurations of audio & video parameters, Dante features, firmware upgrades, and more. For more information, refer to the configuration guide of the SCT-IPCX controller.

HDMI 2.0/USB AV over IP Encoder

8. Customer Service

The return of a product to our Customer Service implies the full agreement of the terms and conditions hereinafter. These terms and conditions may be changed without prior notice.

8.1. Warranty

The limited warranty period of the product is fixed three years.

8.2. Scope

These terms and conditions of Customer Service apply to the customer service provided for the products or any other items sold by authorized distributor only.

8.3. Warranty Exclusion:

- Warranty expiration.
- Factory applied serial number has been altered or removed from the product.
- Damage, deterioration or malfunction caused by:
 - ✓ Normal wear and tear.
 - ✓ Use of supplies or parts not meeting our specifications.
 - ✓ No certificate or invoice as the proof of warranty.
 - ✓ The product model showed on the warranty card does not match with the model of the product for repairing or had been altered.
 - ✓ Damage caused by force majeure.
 - ✓ Servicing not authorized by distributor.
 - ✓ Any other causes which does not relate to a product defect.
- Shipping fees, installation or labor charges for installation or setup of the product.

8.4. Documentation:

Customer Service will accept defective product(s) in the scope of warranty coverage at the sole condition that the defeat has been clearly defined, and upon reception of the documents or copy of invoice, indicating the date of purchase, the type of product, the serial number, and the name of distributor.

Remarks: Please contact your local distributor for further assistance or solutions.

HDMI 2.0/USB AV over IP Encoder



syscomtec Distribution AG

Keltenring 11

D-82041 Oberhaching (bei München)

Tel.: +49 89 666 109 330

Email: post@syscomtec.com

<https://www.syscomtec.com>