

Thank you for purchasing 19RM-001

The 19RM-001 is a multi-mounting rack that offers the flexibility to mount up to eight(8) Ophit's 4K optical extender products(FTDS/ FTHS). www.ophit.com



User's Guide

Product Description

OPHIT 19RM-001 is a multi-mounting rack that offers the flexibility to mount up to eight(8) Ophit's 4K optical extender products as below

*FTDS: 4K Displayport 1.2 optical extender

*FTHS: 4K HDMI 2.0 optical extender

Each fiber optical extender can be powered from 19RM-001. 19RM-001 uses 100-240VAC, 50-60Hz of dual input power with load-sharing and redundant back-up.

19RM-001 adopts two(2) LEDs in the front panel for power supply, these LEDs are as indicator whether to working internal SMPS.

Check your package

Check the package and make sure you have everything:

Contents

- (1) 19RM-001
- (2) Optic Fiber Cable : OM3 1Ch SC 220mm (8)pcs
- (3) Power connection cable for Fiber Optic Extender (8)pcs
- (4) Power cord (2)pcs
- (5) 3x5 Washer Nickel Screw-(8)pcs
- (6) User's Guide

If any of these items are missing in your package, contact OPHIT or your supplier for support.

NOTE: Package content may differ if you have placed a special order or placed order from anywhere other than OPHIT CO., LTD. OPHIT CO., LTD. reserves the right to make changes without further notice to a product described herein to improve reliability, design, packaging or function.



Installation Steps:

1. Remove the "Foot rubber" of the 4K Fiber Optic Extender products.



2. Disassemble the screw of product side.



- Install the 4K optical extender into the 19RM-001.
 Match hole of the 19RM-001 bracket with hole of the 4K optical extender



5. Tighten the screw securely.





User's Guide

Installation

6. Connected the fiber optic cable, DC power jack.





Fig. 4K optical extender image

- 7. Connect two(2) AC plugs to inlet of 19RM-001.
 - 19RM-001 has load shared dual power supplies to run the system stable without any disruption. So it is highly recommended to connect separate power source to AC IN1 and AC IN2 to avoid power failure problem.
- 8. Turn on PS1 and PS2.





User's Guide Installation 9. Check the LED of Powers change to Blue. ** The 4K 1Ch Fiber Optic Extenders are separately sold. HDMI type(FTHS) DispalyPort type(FTDS)



Warranty

We, OPHIT hereby warrant the final purchase of our product as follows. In the case of troubles on our products, please contact the shop purchased.

One year limited warranty

Our customers have right to be served with free of charge when there is trouble in this product during 1(one) year from the day purchased.

Out of warranty services

When you request services (in the case of non manufacturing defects but the troubles by misusage), may served with charge as follows.

- Defects of products caused by accident, disaster.
- Damages of products caused by the customer's carelessness or mistaken application.
- Damages of products caused by the application of the parts or products not supplied or sold by our company.
- Damages of products and related defects caused by not our staff or the men or group not nominated by us for services.

The interchanged parts and products for maintenance services shall be replaced as new parts and products operating normally, and the inter-changed parts and products shall be subjected to our company.

www.ophit.com



RMA Request Form

RMA No.:

Customer Name:		Return Date:	
Company Name:		Phone:	
Model Name:		E-Mail:	
Serial No:		Place of Purchase:	
Address: (For RMA Return)			
RMA details: (Please describe RMA status, application used and failure symptom)			

www.ophit.com



Technical and Sales Support

KOREA HQ

OPHIT CO., LTD.

3F Suntechnovil, 5-27 Mangpo-Dong, Youngtong-Gu, Suwon-City,
Kyunggi-Do, Korea (16681)

Tel: + 82 (0)31 695 5543 Fax: + 82 (0)31 695 5545

E-Mail

jhchoi35@ophit.com

Regional Office

USA
Foreseeson Custom Display
2210E, Winston Road Anaheim,
CA 92806 USA
Tel: +1-714 300 0540
Fax: +1-714 300 0546
E-mail: jhan@foreseesonusa.com

UK Foreseeson UK Ltd Unit 71 Barwell Business Park, Leatherhead road, Chessington, Surrey, KT9 2NY UK Tel: +44 (0) 208 396 1047 Fax: +44 (0) 208 391 4953 E-mail: jason.kwon@fsnmed.eu

Europe Foreseeson GmbH Industriestrasse 38a 63150 Heusenstamm, Germany TEL: +49 (0) 6104-643980 FAX: +49 (0) 6104-64398-11 E-mail: jason.kwon@fsnmed.eu

www.ophit.com

